

BROOKS & LYNDHURST

P.O. Box 2056, Livingston, EH54 0JQ



INSTRUCTIONS FOR THE Zeni RANGE

To remove clips:

Hold the frame in your left hand with the lenses facing into your palm and one of the temples facing upwards.

Unhook the temple frame by pressing both wire bits of the temple's frame together with your left hand and releasing the hook with your right hand. Slide the clip out.

To insert clips:

Hold the frame in your left hand with the lenses facing into your palm and one of the temples facing upwards. Unhook the temple frame.

Slide in the replacement clip.

Please ensure that the temple frame wires sit in the grooves on each edge of the clip. This enables the clip to be held securely and the temple to be hooked and unhooked easily.

- Note: For left-handed users, please reverse the above instructions.

Brooks & Lyndhurst

Telephone: 0845 604 7305

Website: www.brooksandlyndhurst.co.uk

E-mail: info@brooksandlyndhurst.co.uk

You Tube: <http://youtube.com/user/ZenkaUK>

Twitter: <http://twitter.com/ZenkaUK>

Facebook: <http://www.facebook.com/pages/Zenka-UK-Designer-Frames-from-Brooks-Lyndhurst/133167496695151>